

DAC-200ts USE IR Remote Codes

All codes - to Philips RC-5 standard

Key Printing	Function	System	Command	Notes
POWER	POWER ON / OFF	0x04	0x0C	
MUTE	MUTE	0x04	0x36	
SRC	UPSAMPLING	0x04	0x21	
BRIGHT	BRIGHT	0x04	0x29	
1	NUMBER KEY PAD 1	0x04	0x0E	
2	NUMBER KEY PAD 2	0x04	0x0B	
3	NUMBER KEY PAD 3	0x04	0x1E	
4	NUMBER KEY PAD 4	0x04	0x01	
5	NUMBER KEY PAD 5	0x04	0x02	
6	NUMBER KEY PAD 6	0x04	0x03	
7	NUMBER KEY PAD 7	0x04	0x04	
8	NUMBER KEY PAD 8	0x04	0x05	
9	NUMBER KEY PAD 9	0x04	0x06	
+10	NUMBER KEY PAD +10	0x04	0x07	
VOLUME -	VOLUME DOWN	0x04	0x25	
VOLUME +	VOLUME UP	0x04	0x20	
CLOCK IN	WORD CLOCK IN	0x04	0x30	
OPTICAL	OPTICAL INPUT	0x04	0x37	
CD	CD INPUT	0x04	0x1B	
USB	PC-USB INPUT	0x04	0x39	
COAXIAL 1	COAXIAL 1 INPUT	0x04	0x3A	
COAXIAL 2	COAXIAL 2 INPUT	0x04	0x3B	
AES/EBU	AES/EBU INPUT	0x04	0x32	
BLUETOOTH	BLUETOOTH INPUT	0x04	0x3F	
TUBE	TUBE OUTPUT	0x04	0x2E	
AMPLIFIER USE ONLY				
POWER	POWER ON/OFF	0x04	0x24	
MUTE	MUTE	0x04	0x1D	
MODE 1	MODE 1	0x04	0x2F	
MODE 2	MODE 2	0x04	0x1C	
- INPUT	INPUT SELECTOR DOWN	0x04	0x31	
INPUT +	INPUT SELECTOR UP	0x04	0x33	
< BALANCE	BALANCE LEFT	0x04	0x3D	
BALANCE >	BALANCE RIGHT	0x04	0x38	
- VOLUME	VOLUME DOWN	0x04	0x0D	
VOLUME +	VOLUME UP	0x04	0x2C	